

## **Calibration:**

### **Preliminary Considerations**

The accuracy of the LoadMaxx Tractor Scale depends on the accuracy of the certified scale used to calibrate or check-weigh. Ensure that the in-ground scale is reliable, recently certified and in good repair. It is preferable to obtain all weight tickets from the same certified scale. This ensures comparative accuracy. Segmented scales, those that provide individual axle group weights, are preferred. When segmented scales are not available, take extra precaution in calculating weights.

For the best calibration results, the tractor or trailer should be:

- **Parked on level ground**
- **Full tank of fuel**
- **Brakes released**
- **Engine running**

Once the LoadMaxx Tractor Scale is calibrated, it is not necessary to re-calibrate unless the suspension characteristics change.